

Clearing the fault history for some Norcold® refrigerators with the Dinosaur 6212XX board installed.

IF you experience a NO COOLING code as soon as the refrigerator is turned on you might need to erase the fault history. To access the diagnostic mode of your optical board and reset the fault history please follow these instructions.

SINGLE DIGIT DISPLAY:

1. With the refrigerator turned "ON" press and hold the "TEMP SET" and "MODE" buttons at the same time. Release both buttons when "1" shows on the display.
2. Press the "MODE" button until "6" appears, and release the button.
3. After a short pause the "6" disappears and will be replaced by "E" [short pause] "r".
4. After "E" [short pause] "r" displays, press and hold the "TEMP SET" button until the letters "C" [short pause] "L" show on the display.
5. wait at least 5 seconds and then press and hold the "TEMP SET" button until the letters "E" and "r" show again.
6. Turn the refrigerator "OFF" and "ON" to get out of the diagnostic mode.

DOUBLE DIGIT DISPLAY:

1. With the refrigerator turned "ON" press and hold the "TEMP SET" and "MODE" buttons at the same time. Release both buttons when "1" or "11" shows on the display.
2. Press the "MODE" button until "6" or "16" appears, and release the button.
3. After a short pause the "6" or "16" disappears and will be replaced by "Er".
4. After "Er" is displayed press and hold the "TEMP SET" button until the letters "CL" show on the display.
5. Wait at least 5 seconds and then press and hold the "TEMP SET" button until the letters "Er" show again.
6. Turn the refrigerator "OFF" and "ON" to get out of the diagnostic mode.