



# Dinosaur Electronics

1160 Se 27th ST.  
Lincoln City, OR 97367  
Phone: (541) 994-4344

## Thermistor Adjuster for Dometic® refrigerators

### **For "fixed" temperature refrigerators that are not getting sufficiently cold.**

Remove the cover from the black box, making the thermistor cable accessible. Unplug the two pin thermistor cable from the control board and plug in the adjuster. Plug the thermistor into the female side of the adjuster. If you want the refrigerator to be "slightly" colder turn the dial to the right, for a "much" colder refrigerator turn the dial to the left.

If you are looking for a more accurate adjustment this product can be used along with our Thermistor Simulator for Dometic® products. To accomplish the more accurate setting, remove the cover from the control box, making the thermistor cable accessible. Unplug the two pin thermistor cable from the control board and plug in the adjuster. Plug Dinosaur's Thermistor Simulator for Dometics® into the female side of the adjuster. Preset the Simulator to your desired temperature. Start with the knob of the Thermistor Adjuster on the Warmest setting (far right on the dial), and slowly turn the dial to the left until the heat source shuts OFF. Now disconnect the Thermistor Simulator and plug the actual thermistor into the female side of the Adjuster and your good to go.